Comparison Chart – 911Tracker and LoJack

Product Capabilities & Features	911Tracker [®] T3	LoJack®	LoJack [®] With Early Warning
Is device a theft prevention system or a theft recovery system?	Tracker is a theft prevention & recovery system. Tracker notifies the owner of a theft immediately so owner can explain the theft to 911 located nearest the vehicle. This helps police stop the thief before they get to the chop shop.	LoJack is a theft recovery system. The owner must determine their vehicle is stolen first and then file a stolen vehicle report so the LoJack location system can be activated.	LoJack is a theft recovery system. Early Warning version provides a Keychain Fob that must be in the vehicle when it is driven.
What is coverage in the U.S.?	Nationwide cellular coverage		Only in cities with police departments that are equipped with LoJack radios
Does device notify owner of theft?	Yes – Tracker sends SMS text within a few seconds.	No for standard LoJack.	Early Warning detects movement and if no Keychain Fob is present, owner receives message 15 to 60 minutes after movement.
How are police notified of a theft?	Owner calls Tracker and presses # for 3-party conference call with 911 that is nearest the vehicle.	Standard LoJack – Owner must discover vehicle is missing and call police and file a stolen vehicle report.	When Early Warning notifies owner, the owner calls police and files a stolen vehicle report.
How do police get vehicle location?	During the 3-party call, the police will automatically see the Tracker location using their normal E911 system.	After police have stolen vehicle report, they activate LoJack device transmitter so police vehicles with LoJack receivers can receive.	After police have stolen vehicle report, they activate LoJack device transmitter so police vehicles with LoJack receivers can receive.
Can police receive more accurate vehicle location?	Yes. If police wish to get the real-time Tracker GPS location, they press 3 on their keypad to hear the Tracker speak real-time location, speed, and direction.	Yes. Police can get accurate location by positioning three police vehicles with LoJack receivers to triangulate the position.	Yes. Police can get accurate location by positioning three police vehicles with LoJack receivers to triangulate the position.
Do owners need to register with police?	No police registration is needed.	Yes. Owner must contact LoJack to provide vehicle VIN number so LoJack can submit to statewide law enforcement computer system.	Yes. Owner must contact LoJack to provide vehicle VIN number so LoJack can submit to statewide law enforcement computer system.
Can I install the device?	Yes. Tracker cable has 4- wires that can be installed by the owner or normal stereo / security shop.	No. LoJack requires that a LoJack authorized dealer install in the vehicle.	No. LoJack requires that a LoJack authorized dealer install in the vehicle.
If vehicle existing security alarm is tripped, does device notify owner?	Yes. Tracker can notify owner if existing vehicle alarm is triggered.	No. LoJack does not monitor vehicle alarm.	No. LoJack does not monitor vehicle alarm.
Does device require maintenance?	No. Tracker backup remains charged from vehicle battery. Does not have key fob.	Yes. LoJack battery is not re- chargeable and LoJack requires that it must be changed every 2 years by LoJack approved shop, which costs \$70 to \$100.	Yes. LoJack battery is not re- chargeable and LoJack requires that it must be changed every 2 years by LoJack approved shop, which costs \$70 to \$100.
Does key fob require maintenance?	No. Tracker does not have key fob.	No. Standard LoJack does not have key fob.	Yes. Owner must change battery in Keychain Fob to prevent false notification.

Yes. Install a Cable Kit [\$39] in each vehicle. Unplug the Tracker from one vehicle and move to another.	No. Device is coded to vehicle VIN number and cannot be moved.	No. Device is coded to vehicle VIN number and cannot be moved.
Tracker in normal Guard mode automatically monitors vehicle ignition, so notification will be enabled only when ignition is turned off.	When the owner calls police to file a stolen vehicle report, the police will activate LoJack device.	When the owner calls police to file a stolen vehicle report, the police will activate LoJack device.
Yes. Tracker in Master mode will notify owner if valet travels just a few blocks.	No. Owner must provide keyfob with key to prevent false notification.	No. Owner must provide keyfob with key to prevent false notification.
Yes. Tracker in Master mode will notify owner if thief travels just a few blocks.	No.	Yes, Early Warning will alert you if the Keychain Fob is not in the vehicle.
No. You can place Tracker in Move mode to temporarily stop notification.	No. However owner must provide keyfob with key to prevent false notification.	No. However owner must provide keyfob with key to prevent false notification.
Yes. Owner can send SMS text to get location, speed, and direction anytime they wish.	No. LoJack does not provide location to owner.	No. LoJack does not provide location to owner.
Yes. Owner can send SMS text to disable the vehicle starter. This does not stop the moving vehicle but stops the thief from restarting the vehicle.	No.	No.
Yes. Tracker will notify owner if vehicle battery is getting low.	No. LoJack does not monitor vehicle battery.	No. LoJack does not monitor vehicle battery. However, Keychain Fob flashes if its battery is low.
Yes. The owner can add two emergency contacts to be notified.	No.	Yes. Early Warning lets the owner add 4 additional contact numbers.
T3 price is \$225 Service Plan is \$11.49/mo or \$119/yr. No activation fee. No contract. No cancellation fee.	Standard LoJack is \$650. No monthly service.	LoJack with Early Warning option is \$950. No monthly service.
	in each vehicle. Unplug the Tracker from one vehicle and move to another. Tracker in normal Guard mode automatically monitors vehicle ignition, so notification will be enabled only when ignition is turned off. Yes. Tracker in Master mode will notify owner if valet travels just a few blocks. Yes. Tracker in Master mode will notify owner if thief travels just a few blocks. No. You can place Tracker in Move mode to temporarily stop notification. Yes. Owner can send SMS text to get location, speed, and direction anytime they wish. Yes. Owner can send SMS text to disable the vehicle starter. This does not stop the moving vehicle but stops the thief from restarting the vehicle. Yes. Tracker will notify owner if vehicle battery is getting low. Yes. The owner can add two emergency contacts to be notified. T3 price is \$225 Service Plan is \$11.49/mo or \$119/yr. No activation fee. No	in each vehicle. Unplug the Tracker from one vehicle and move to another.No. Device is coded to vehicle vehicle will number and cannot be moved.Tracker in normal Guard mode automatically monitors vehicle ignition, so notification will be enabled only when ignition is turned off.When the owner calls police to file a stolen vehicle report, the police will activate LoJack device.Yes. Tracker in Master mode will notify owner if valet travels just a few blocks.No. Owner must provide keyfob with key to prevent false notification.Yes. Tracker in Master mode will notify owner if thief travels just a few blocks.No. However owner must provide keyfob with key to prevent false notification.Yes. Owner can place Tracker in Move mode to temporarily stop notification.No. However owner must provide keyfob with key to provide keyfob wi